
Scanner

The scanner is intended for you to use to scan photo prints to make digital copies for personal use and storage.

STOP

Do you have…

- ☐ A computer
- ☐ A USB port **embedded into your computer** (note - a dongle attachment does not supply enough power for the scanner



- ☐ Understanding of downloading and installing software from the internet


If yes, continue! If not….

---

1. Install software
    a. Visit http://epson.com/support
    b. Type “Epson Perfection V19 II” into the search bar, and click on the exact result
    c. Choose your computer’s operating system.
        i. If you do not know, Google how to find it with your computer type
    d. DO NOT DOWNLOAD THE “RECOMMENDED” PACgftr0
    KAGE - this will try to make you register the scanner
        i. Instead, click “Drivers” and download “Scanner Driver and Epson Scan 2 Utility v6.7.82.0”
    e. Open the download and follow the instructions to install


f. Once installed, you can find the “Epson Scan 2” within your computer’s applications and open it

2. Plug in the scanner
    a. Use the cord to plug the scanner into your computer




3. RECOMMENDED: Make a folder on your computer to store the photos BEFORE you start any scanning

4. Place your photo face down on the glass of the scanner and close it.



5. See the image on the following page for guidance on the scanning settings.
    a. Once ready, click “Scan.”



6. Replace the photo and repeat the scanning instructions as many times as you need to!